



YTP-W26

IRONING TABLE

INSTRUCTION MANUAL

Reading the manual carefully before operating

Shanghai Weishi Machinery Co., Ltd

Add: 52 # No. 1089 Qinzhou, Road (N0 Shanghai China

Post Code: 200233

Telephone: 86-21-64953003, 64958277, 64955983

Fax: 64952757

YTP-W26 vacuum ironing table is a kind of ironing table for ironing various fabric of finished product or semi-finished product in garment plants. The physical construction is simple and reasonable, convenience to maintain, high vacuum volume, low noise, easy to operation is the feature of the ironing table.

The YTP vacuum ironing table adopts modular construction, there are many functions can be carried out by adoption of single swing-arm, double swing-arm, electric-heating system or steam-heating system according to different demand of ironing. Various moulds can be equipped according to consumer request for the best effect of ironing.

I. Main Specifications:

| | |
|---------------------------|----------------|
| 1. Motor Power: | 550w |
| 2. Power source: | 380V/50Hz/3P |
| 3. Rotate speed of motor: | 2800rpm |
| 4. Inhaling pressure: | -150Pa |
| 5. Operation noise: | ≤75db |
| 6. Dimension L x W x H | 1200x650x800mm |

II. Construction feature:

1. The **YTP** vacuum ironing table consists of frame, ironing plate, centrifugal draft fan, swing-arm, air draft turning device and lever bracket etc.
2. Special padding and cover is adopted over the ironing plate, suitable to operate.
3. Electrostatic spraying is adopted at surface of the ironing table, so it is serviceable and rustless.

III. Installation and operation:

1. The ground where the ironing table installed must be stability and leveling.
2. Before the installation of the machine, please check the voltage and capability of the power source, be sure to connect the earth lead.
3. Press the green button, the power indicator light up, the electric motor rotate, the ironing table in status of induced draft.
4. Step the foot plate, air draft turning device can control the induced draft between ironing plate and swing-arm.

IV. Maintenance:

1. Clean the electric motor and impeller periodically, compressed air can be used to clean out the dust and fiber.
2. It is necessary to lubricate the rotary parts frequently, such as the footplate etc.
3. The dust, fiber and sizing material will contaminate the cover and padding over the ironing plate and mould and abate vacuum volume of the machine. The cover and padding must be cleaned every month, the padding must be replaced timely if it is life-time service.

Packing List

| DESCRIP-TION | UNIT | QUAN-TITY | MODEL | | PRODUCT CODE | |
|--------------|----------------|-----------|-----------------------|--------|--------------|---------|
| Case No. | set | 1 | YTP-W26 | | | |
| | DIMENSIONS(mm) | | Vol.(m ³) | NW(Kg) | GW(Kg) | REMARKS |
| | | | | | | |
| | | | | | | |

| NO. | TECHNIQUE DOCUMENT | UNIT | QUANTITY |
|--|------------------------|-------|----------|
| 1 | Operation manual | piece | 1 |
| 2 | Certificate of quality | piece | 1 |
| Inspector_____ Packer_____ Packing date_____ | | | |

CERTIFICATE OF QUALITY

质量证明

Model No. YTP-W26
产品型号

Name _____
产品名称.

Serial No. _____
产品序号

This machine has been successfully inspected and is allowed to sell
该产品已检验合格并准予出售

Inspector: _____ Dean: _____ Principal: _____

检验员: 质检科负责人: 厂长:

Date: Year Month Day
检验日期: 年 月 日